



PREPARATION AND APPLICATION PROCEDURE

BRICK AND TILE

PREPARATION	FINISH	SEALANT
<p>Procedure:</p> <ul style="list-style-type: none"> - Rinse the surface thoroughly with a 2500 lb. pressure washer. - Clean with TexNov Surface Preparer. - Vigorously brush the surface and let sit for 15 minutes keeping the surface wet. - Rinse the surface thoroughly with a pressure washer. - Let the surface dry over a 48-hour period of good weather. 	<p>Procedure:</p> <ul style="list-style-type: none"> - In warm weather dilute with water (50 ml/liter) for ease of application. - Apply two coats of TexNov Acrylic Coating. Use a brush or roller with 10 mm bristles (24 hours between each coat). - Let the surface dry for 24 hours. <p>Note: TexNov Acrylic Coating can be applied to almost every type of brick or concrete roof tiles on condition the roof is in good shape.</p>	<p>Procedure:</p> <ul style="list-style-type: none"> - You can apply TexNov WRS-40 Sealant (waterproof sealant) to seal the surface. (Optional) Use a brush or a roller with 10 mm bristles or a sprayer. - Let the surface dry for 24 hours.

Maintenance: Clean the surface with **TexNov Surface Preparer** (6 water / 1 Preparer). Let dry and add a coat of **WRS-40** Sealant every 5 years or as needed. This should enable you to keep your surface in good condition.

