



## PREPARATION AND APPLICATION PROCEDURE

# FRESHLY POURED CONCRETE

### SEALANT

For a freshly poured concrete floor done on the same day.

**Procedure:** Once concrete surface is dry (as soon as you can walk on it). Apply the **TexNov Met-30** Sealant as a curing agent. Use a brush or a roller with 10 mm bristles or a sprayer.



### ⚠ CAUTION

Never place rubber mats on an acrylic floor even if there is a sealer. Accumulated moisture could affect the acrylic coating.

Do not use magnesium chloride (de-icing salt) on surfaces with acrylic coating as it could damage your surfaces including concrete.