



## PREPARATION AND APPLICATION PROCEDURE

# GREEN WOOD

### PREPARATION

It is not recommended to install TexNov Acrylic Coating on wood that has not been dried (or wood that is still green).