



PREPARATION AND APPLICATION PROCEDURE

PAVING STONES

PREPARATION	SEALANT
<p>Procedure:</p> <ul style="list-style-type: none"> - Rinse the surface with a 3500 lb. pressure washer with rotating nozzle. - Clean with TexNov Surface Preparer. - Vigorously brush the surface and allow 15 minutes for it to act keeping the surface wet. - Rinse the surface thoroughly with a pressure washer. - Let the surface dry over a period of 48 hours of good weather before applying the sealant. 	<p>After preparing the surface:</p> <p>Procedure:</p> <ul style="list-style-type: none"> - Directly apply 2 coats of Met-HD Sealant (48 hours between each coat) onto the surface. Use a brush or roller with 10 mm bristles. - Let the surface dry for 24 hours.

Maintenance: Clean the surface with **TexNov Surface Preparer** (6 water / 1 Preparer). Let dry and add a coat of **Met-HD Sealant** every 3 years or as needed. This should enable you to keep your surface in good condition.



⚠ CAUTION

Never place rubber mats on an acrylic floor even if there is a sealer. Accumulated moisture could affect the acrylic coating.

Do not use magnesium chloride (de-icing salt) on surfaces with acrylic coating as it could damage your surfaces including concrete.