PREPARATION AND APPLICATION PROCEDURE

PAVING STONES

PREPARATION	SEALANT
Procedure: - Rinse the surface with a 3500 lb. pressure washer with rotating nozzle. - Clean with ***TexNov Surface Cleaner***. - Vigorously brush the surface and allow 15 minutes for it to act keeping the surface wet. - Rinse the surface thoroughly with a pressure washer. - Let the surface dry over a period of 48 hours of good weather before applying the sealant.	**After preparing the surface:** **Procedure:** - Directly apply 2 coats of ***Met-HD*** Sealant (48 hours between each coat) onto the surface. Use a paintbrush or roller with 10 mm bristles. - Let the surface dry for 24 hours.

Maintenance: *Clean the surface with* ***TexNov Surface Cleaner*** *(6 water / 1 Cleaner). Let dry and add a coat of* ***Met-HD*** *Sealant every 3 years or as needed. This should enable you to keep your surface in good condition.*

⚠ CAUTION

Never place rubber mats on an acrylic floor even if there is a sealer. Accumulated moisture could affect the acrylic coating.

Do not use magnesium chloride (de-icing salt) on surfaces with acrylic coating as it could damage your surfaces including concrete.

OPEN QUANTITY CALCULATOR

TexNov
839 Joseph-Louis-Mathieu, Sherbrooke J1R 0X3
www.texnov.com - info@texnov.com
1 877 316-6388

The application instructions and performance characteristics are based on information we believe to be reliable. They are offered to the best of our knowledge, but without guarantee, as conditions and methods of use of our products are beyond our control.