



# PREPARATION AND APPLICATION PROCEDURE

## STONE EFFECT COATING

PREPARATION	FINISH COATING	SEALANT
<b>Procedure:</b> <ul style="list-style-type: none"> <li>- Rinse the surface well with a pressure washer.</li> <li>- Apply <b>TexNov Surface Preparer</b> according to the dilution table.</li> <li>- Brush the surface vigorously and leave for 15 minutes.</li> <li>- Rinse the surface thoroughly with a pressure washer.</li> <li>- Allow the surface to dry for 24 hours in good weather before applying the finishing coat.</li> </ul>	<b>Procedure:</b> <ul style="list-style-type: none"> <li>- Apply 2 coats of <b>TexNov Acrylic Coating</b>, using a brush or roller with 10 mm bristles.</li> <li>- Allow 24 hours drying time between coats.</li> <li>- Allow the surface to dry for 24 hours before applying the sealant.</li> </ul>	<b>Procedure:</b> <ul style="list-style-type: none"> <li>- Apply 2 coats of <b>Met-30 TexNov sealer</b>, using a brush or roller with 10 mm bristles.</li> <li>- Allow 24 hours of good weather to dry between coats.</li> <li>- Let the surface dry for 24 hours.</li> </ul>

**Maintenance:** Clean the surface with *TexNov Surface Preparer* by diluting 9 parts of water and 1 part of *Preparer*. Let dry and add a coat of *Met-30 Sealer* every 3 years or as needed, which should allow you to keep your surface in good condition

