

PREPARATION AND APPLICATION PROCEDURE **ALUMINUM SIDING**

PREPARATION	FINISH	SEALANT
Procedure: - Rinse the surface well with a 2000 lb. pressure washer. - Apply and scrub the <i>TexNov Surface Preparer</i> . - Let act for 15 minutes by keeping the surface wet. - Rinse the surface thoroughly with a pressure washer. - Let the surface dry for 24 hours prior to applying the finish coating. Note: In places where there is rust, apply a primer to metal previously.	After preparing the surface: Procedure: - In warm weather dilute with water (50 ml/liter) for ease of application The temperature of the surface should not exceed 30° C at the application Apply 2 coats of TexNov Acrylic Coating. Use a brush or roller with 10 mm bristles (24 hours between applying each coat).	After preparing the surface and applying the coating: Procedure: - To obtain a surface that will remain beautiful for a long time, apply TexNov Met-30 Sealant or TexNov WRS-40 Sealant for horizontal surfaces. Use a brush or roller with 10 mm bristles or a sprayer. - Let the surface dry for 24 hours.
	- Let the surface dry for 24 hours.	

Maintenance: Clean the surface with TexNov Surface Preparer (6 water / 1 Preparer). Let dry and add a coat of Met-30 Sealant.

