

finishing coat for a uniform result.

We must sand the traces of trowels visible later.

## PREPARATION AND APPLICATION PROCEDURE CONCRETE FOUNDATION

## **PREPARATION FINISH** Procedure: Procedure: - If your Foundation is covered with old roughcast which is coming off or any other unstable materials, remove them by - Apply two coats of TexNov using the appropriate tools. Remove any paint using a sandblaster, a diamond grinder or any other suitable means. Acrylic Coating. Use a brush or - Clean the surface with a 3500 lb., rotary, jet pressure washer, gasoline motor. (Available at tool rental centers.) roller with 10 mm bristles - In a clean container, dilute *TexNov Concrete Conditioner* with 50% water. (24 hours between each coat). - The concrete surface must be wet when applying the *TexNov Concrete Conditioner*. - Apply the TexNov Surface Cleaner Mix. on the surface with a sprayer and leave on for 10 to 15 minutes as needed - In warm weather dilute with brush vigorously and rinse thoroughly with a pressure washer water (50 ml / liter) for ease of - Let the surface dry for 48 hours of good weather. application. - Repair cracks with TexNov All Purpose Polymer or TexNov 200. - Apply a layer of TexNov All Purpose Polymer OR TexNov 200 before the application of the finishing coat. - Allow the surface to dry for 24 hours. - All imperfections, metal rods, etc... must be repaired with TexNov Polymer or TexNov 200 before applying the

Maintenance: Clean the surface with TexNov Surface Preparer (4 water / 1 Preparer).

- For a flawless result, it is recommended to install one to two coats of **TexNov 200** incorporating a fiberglass mesh.



