



PREPARATION AND APPLICATION PROCEDURE

PLYWOOD

PREPARATION	ADHESION MEMBRANE	FINISH	SEALANT
Procedure: <ul style="list-style-type: none"> - Clean with Texnov Surface Preparer. - Let the surface dry for 48 hours. - Caulk your joints with elastomeric polyurethane caulking (e.g.: Adbond 009, Sonneborn NP1 caulking or equivalent) taking care to caulk only the joints. - Sand well to <u>roughen the surface</u> (with 60 grain sandpaper). 	Procedure : <ul style="list-style-type: none"> - Apply one coat of TexPro FlexStop RLX on the substrate. Use a brush or roller with 10 mm bristles. - Let the surface dry for 24 hours. 	Procedure: <ul style="list-style-type: none"> - In warm weather dilute with water (50 ml/liter) for ease of application. - You can fill the screw heads with TexNov Acrylic Coating (screws should be rust proof: zinc, ceramic). - Apply 2 coats of TexNov Acrylic Coating. Use a brush or roller with 10 mm bristles (24 hours between applying each coat of sealant). - Let the surface dry for a 24-hour period before applying the sealant. Note: TexNov Acrylic Coating will not hide all defects due to an unevenly installed substrate.	Procedure: <ul style="list-style-type: none"> - Apply 2 coats of Met-30 Sealant. Use a brush or roller with 10 mm bristles (24 hours between each coat). - Let the surface dry for 24 hours. Note: All wood surfaces located less than 60" from the ground or poorly ventilated should ideally be sealed on all sides with Met-30 Sealant. This will prevent premature deterioration of the wood due to the migration of moisture from the ground to the sky.

Maintenance: Clean the surface with **TexNov Surface Preparer** (6 water / 1 Preparer). Let dry and add a coat of **Met-30** Sealant every 3 years or as needed. This should enable you to keep your surface in good condition.

