



PREPARATION AND APPLICATION PROCEDURE

ROUGHCAST

PREPARATION	FINISH
<p>Procedure:</p> <ul style="list-style-type: none">- If your foundation is covered with old plaster which is ungluing or any other unstable materials, remove them by using the appropriate tools.- Clean the surface with a rotary jet, 2500 lb. pressure washer, gasoline motor. (Available at tool rental centers.) This will also allow you to verify the adhesion of the plaster to the substrate.- In a clean container, dilute the TexNov Concrete Conditioner reduced with 50% water.- The concrete surface must be wet when applying TexNov Concrete Conditioner.- Vigorously brush the surface with the TexNov Concrete Conditioner.- Rinse thoroughly with the pressure washer.- Let the surface dry over a period of 48 hours of good weather before applying the finish coating. <p>Note: All defects, metal rods, etc... must be repaired with TexNov All-purpose Polymer or TexNov 200 before applying the coloured TexNov Acrylic Coating for a smooth result.</p>	<p>Procedure:</p> <ul style="list-style-type: none">- Apply two coats of TexNov Acrylic Coating. Use a brush or roller with 10 mm bristles (24 hours between each coat).- Let the surface dry for 24 hours.

Maintenance: Clean the surface with **TexNov Surface Preparer** (6 water / 1 Preparer).

